



# VTech Touch and Swipe Baby Phone Battery Replacement

The first thing you will need to do before replacing any of the parts in your VTech baby phone, is remove the batteries. For many common issues, simply replacing the batteries will fix the problem.

Written By: Zack Drawdy



## INTRODUCTION

One common issue that many people have had in regards to their VTech baby phone was song looping, which may be a result of low battery charge. If replacing the batteries does not solve your problem, this guide will still get you started on replacing all the other items inside the device.

---



### TOOLS:


- [Phillips #1 Screwdriver](#) (1)
-

## Step 1 — Battery



- Using a Phillips #1 screwdriver, remove the 4.8mm Phillips #1 screw on the battery cover by twisting the screwdriver counter-clockwise.

## Step 2



- Then simply remove the two AAA batteries by pulling on one end of the battery and lifting it straight out.



## Step 3



- Take care when you want to close it. There is a notch.
- First you have to hook up that notch.
- Then firmly use a PH1 screwdriver to secure it.

---

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-16 05:58:05 PM.